

Scan "Restore USA Factory Configuration First. Wait for green light to stop blinking and then a set of beeps. Then Enter Programming Mode. Scan all 10 Barcodes, then Exit Programming mode.



1 Restore USA Factory Configuration



2 ENTER/EXIT PROGRAMMING MODE



3 UPC-A Check Character Transmission = Don't Send



4 UPC-E Check Character Transmission = Don't Send




5 EAN 8 Check Character Transmission = Don't Send



6 EAN 13 Check Character Transmission = Don't Send



7 Code 39 CIP = Enable



8 Aiming Pointer = Enable



9 UPC-A Number System Character = Do not transmit



10 UPC-E Number System Character = Do not transmit



11 GS1-128 = Transmit in Code 128 data format



12 EAN-13 Flag 1 Char = Don't transmit



13 ENTER/EXIT PROGRAMMING MODE