

Scan "Restore USA Factory Configuration First. Wait for green light to stop blinking and then a set of beeps. Then Enter Programming Mode. Scan all 10 Barcodes, then Exit Programming mode.



Restore USA Factory Configuration



ENTER/EXIT PROGRAMMING MODE

3



UPC-A Check Character Transmission = Don't Send

8



Aiming Pointer = Enable

4



UPC-E Check Character Transmission = Don't Send

9



UPC-A Number System Character = Do not transmit

5



EAN 8 Check Character Transmission = Don't Send

10



UPC-E Number System Character = Do not transmit

6



EAN 13 Check Character Transmission = Don't Send

11



GS1-128 = Transmit in Code 128 data format

7



Code 39 CIP = Enable

12



EAN-13 Flag 1 Char = Don't transmit

13



ENTER/EXIT PROGRAMMING MODE